



USER MANUAL

A3800 – RELAYS, LOOPS module





Updated: 2025

Content:

Introduction	
Description – relay module Front panel of the module. Bottom panel of the module. Top panel of the module.	4 4 4 5
Description – loop module Front panel of the module. Bottom panel of the module. Top panel of the module.	6
How to make module and A3800 communicate	
More settings	11
ICP error signalization	13
Technical specifications Relay – specifications Loops – specifications	14 14 14

Introduction

Adash also offers relay and loop modules. This manual is used for description of these modules and their specifications.

Relay module is mostly used for signalization in practice. Just to imagine how it can work in practice, see simple scheme below.



Let's explain this scheme. We have connected all components (motor, online unit, relay module and some bulb) together. In this example, imagine, that value 5 mm/s is value of vibration which we would like to know that it is exceeded. For such a situation we can use relay module. We get 5 mm/s value on motor. Online unit will measure this value. This value is in this moment also known to relays – relay is closed. The bulb is lightened up. In that moment we know, that value on the motor exceeded the value we set – 5 mm/s.

Loop module takes advantage of the excellent property of the current - it is well transferred over long distances; therefore, it is possible to "lead" the current out of the high-interference environment. Then it is great to use loop module to identify error states. Every measured value is linearly converted to a 4-20 mA current loop value. Values shown outside of this range are good indicators for error states.



More specifications and descriptions of modules is shown in next chapters.

If you are interested in more information about Adash online units (A3800), you can find them in the manual for online monitoring systems – <u>www.adash.com</u>.

Description – relay module

Relay module is described in this chapter. Relay module specification is in chapter: Technical specifications .

Front panel of the module



Bottom panel of the module



Note:

AUX power is not needed for USB connection. It is needed only for Ethernet connection.

Top panel of the module

Top panel of the relay module is shown in the picture below.



AUX power '+ pole'

Terminal blocks are used to connect supply wire or to connect several wires together in electrical engineering. Where to connect these terminal blocks and how they look like is shown in the following picture. We connect terminal block for relay 1 - 4.

Terminal block (relay 1-4)	Relay module	
Re1 Re2 Re3 Re4		AAAA Ro-SYS X AAAAA B ¹ Ral ^{B2} Ral AAAAA +++ AAAA

You can see top panel of relay module with terminal blocks connected in the following picture.



Description – loop module

Loop module is described in this chapter. Relay module specification is in chapter: Technical specifications.

Front panel of the module



Bottom panel of the module



Note:

AUX power is not needed for USB connection. It is needed only for Ethernet connection.

Top panel of the module



AUX power

Terminal blocks are used to connect supply wire or to connect several wires together in electrical engineering. Where to connect these terminal blocks and how they look like is shown in the following picture. We connect terminal block for loop 1 - 4 and their powering.



You can see top panel of loop module with terminal block connected in the following picture.



How to make module and A3800 communicate

Firstly, you need to connect module to online unit A3800. You do this with USB cable. **USB port (module):**



USB port (online unit A3800):



Next steps described below are for modules which were not set by Adash. Modules and online units A3800 are configured by Adash in production when you order them together.

When module is ordered separately and you already have A3800, you need to configure it by yourself. See following steps to proceed with it further.

Connect to online unit with remote desktop connection. Once you are connected you need to open device manager to configure communication ports (between online unit and module).

There is a different guide how to open device manager based on version of operating system in your online unit.

OS – **Windows 10/11:** click to Windows start button with right mouse button and go to Device manager. **OS** – **Windows 7**: press Win + R and fill in **devmgmt.msc** command (see screenshot below). Confirm with OK and device manager opens.

🖅 Run		×
	Type the name of a program, folder, document, or Internet resource, and Windows will open it for you.	
<u>O</u> pen:	devmgmt.msc	~
	OK Cancel Browse	

Once you have Device manager window opened, go to section for Ports (shown in the next picture).



Find the port where your relay/loop module is connected (in our case it is port COM6). **On which port your module is connected?** Open Ports tab in device manager as shown in the following picture.



Then disconnect the module from online unit. You can see which COM port number is shown/hidden when you connect/disconnect your module.

Click on module port with right mouse button – Properties. Click on Port Settings.

SB Serial Port (COM6) Properties ×	USB Serial Port (COM6) Properties
General Port Settings Driver Details Events	General Port Settings Driver Details Events
USB Serial Port (COM6)	Bits per second: 9600 ~
Device type: Ports (COM & LPT)	Data bits: 8
Location: on USB Serial Converter	Parity: None ~
Device status	Stop bits: 1
This device is working property.	Row control: None
to this device will take effect.	Advanced Restore Defau
OK Cancel	OK Can

Click on Advanced.

COM Port Number set to COM10 as below (it is default port set for communication between A3800 and module).

Advanced Settings for COM6			: ^
COM Port Number:	COM6	J	OK
USB Transfer Sizes Select lower settings to corre	COM6 COM7 COM8 COM9	d rates.	Cance
Select higher settings for f	COM10]	Defaults
Receive (Bytes):	COM12 COM13 COM14		
Transmit (Bytes):	COM15 COM16		
BM Options	COM17 COM18 COM19	Miscellaneous Options	

Confirm with **OK** button (confirm also the 'Properties' window).

Now you need to change config file for online unit. You can find it in this location C:\A3716\data. There is config file with name **VA4.cfg**. Open it with notepad. You need to change this part in config file:

[ONLINE BOARD] port=-1

Port value set to -1 means that online board is not connected. So, we need to change it like this: **[ONLINE BOARD] port=10 baud=115200 wdt=10000 keep vals=off turn off when icp error=1**

Once you paste this into config file, save the changes.

The next step is to create database in DDS and send this project to online unit A3800 (in other words – start data collection – DDS – Online tab – Start) – how to create database in DDS is described in manual for online monitoring systems. It is available on Adash website.

When correct communication between online unit A3800 and module is established you can see LED light on for **RDY** and **PWR**.



More settings

Relay parameters are set in DDS. Relays can be used only for static (e.g. overall values) measurements. You can find it under 'Online' tab in 'Properties' of data cell window. You need to scroll down to see them.

DDS window for relay setting:

ne		[ID: 1]	
O RMS			OK
			Cancel
eading Template (avalaible only for em	ntv cell)		
<no template=""></no>		Delete Templa	te Save as Template
operties Route Limits Data R	eference Online		
Lifebee Velue	22 4		
Higher value	22 mA		~
Signal Overload	24 m A		
Signal Overload	24 mA		
Signal Overload ICP Error Relay	24 mA 3.5 mA	-	
Signal Overload ICP Error Relay Relay	24 mA 3.5 mA 1	1	
Signal Overload ICP Error Relay Relay Activation Value [mm/s]	24 mA 3.5 mA 1 1	1	
Signal Overload ICP Error Relay Relay Activation Value [mm/s] Activation Delay [s]	24 mA 3.5 mA 1 1 0	1	
Signal Overload ICP Error Relay Relay Activation Value [mm/s] Activation Delay [s] Deactivation Delay [s]	24 mA 3.5 mA 1 1 0 0	1	
Signal Overload ICP Error Relay Relay Activation Value [mm/s] Activation Delay [s] Deactivation Delay [s] Latch	24 mA 3.5 mA 1 1 0 0 0 No		

Relay - relay number used

Activation Value – the measured value which switch the relay

Activation/Deactivation Delay [s] – delays for activation and deactivation

Latch – if latch function is used, then deactivation is done only manually. Use REL RST contacts (rear panel) and connect 4-20V to R-(ground) and R1 or R2 (voltage).



As latch relay can be little bit difficult to understand, let's describe it on following example:

The factory initial state of the relay is de-energized (i.e. NC and COM are connected). The ISO RMS (10-1000Hz) value is measured on the machine. When the RMS value will exceed 1 mm/s, then the relay will switch the red light in a control room.

If the Latch = NO (it means do not hold): When the vibration value will decrease under the 1 mm/s, then the relay will switch off the light.

If the Latch = YES, then the relay will not switch off the light when the vibration decreases less than 1 mm/s. The relay keeps the switch ON until it is manually switched off (through the use of REL–RST).

Logical function – logical function OR/AND which is used. This is used when one relay is assigned to more measurements.

For example, imagine that one relay is assigned to ISO RMS on 4 individual points.

Logical function **OR** is used. The relay is activated when at least ONE data cell activates it. When logical function **AND** is used, then relay is activated when ALL 4 data cells activate it.

Loops parameters are set in DDS. Current loops can be used only for static (e.g. overall values) measurements. You can find it under 'Online' tab in 'Properties' of data cell window. You need to scroll down to see them.

DDS window for loop setting:

me		[ID: 1]	
SO RMS			OK
			Cancel
Reading Template (avalaible only for em	pty cell)		
< No template >		P Delete Template	Save as Template
	Contine		
roperties Route Limits Data R	eference Online		
Summary	None		^
Summary Interval (HH:MM)	1:00		
Loop			
Loop	1		
4 mA [mm/s]	0,0		
20 mA [mm/s]	10		
Lower Value	4 mA		
Higher Value	22 mA		
Signal Overload	24 mA		
ICP Error	3.5 mA		
Rolay			
riciay			

Loop - current loop number where measurement is ongoing,

4 mA and 20 mA – the lowest and the highest range for current loops values, the quantity depends of measurement quantity. Based on the example above 0 mm/s is 4 mA on the loop output and 10 mm/s is 20 mA on loop output.

Lower/Higher value – you can set mA values, which are send in case that measured value is under the range or over the range. It means, when measured value is out of the range 0 – 10 mm/s, you define what value is shown on the output. Example: we set this range for current loops: 0 mm/s as 4 mA, 10 mm/s is set to 20 mA. Measured value is 12 mm/s. It means that this value is higher than defined range values. Based on the screenshot Higher Value is set to 22 mA. So, in the current loop output is value 22 mA. It works the same way for the parameter Lower Value.

Signal overload – mA value sent when the module input is overloaded.

ICP Error – mA value sent in case of ICP[®] error.

ICP error signalization

In case of relay module, there is an option to signalize ICP error for sensors. For example, if the cable is corrupted or sensor is not working you can use this option of relay disconnection. What this actually means? When you turn on this function and cable connected to relay is corrupted, the system relay is closed (disconnected). It means that RDY LED turns off. In this case, you know that ICP error occurred.



How to set it correctly in configuration file?

As mentioned in chapters above, it depends if you order module with online unit A3800 or separately. If module is already set from production, this function (to disconnect the relay) is automatically turned on. If you order module separately, you need to set it according to following steps.

Go to config file – you find it in this location C:\A3716\data – config file is named VA4.cfg.

Find section for online board: [ONLINE BOARD] port=-1

This section you need to change. [ONLINE BOARD] port=10 baud=115200 wdt=10000 keep vals=off turn off when icp error=1

Technical specifications

Relay – specifications

OUTPUTS

Outputs: Switch. voltage MAX: Switch. current MAX:

16x relay SPDT 125 VAC, 60 VDC 1 A

Sys Output: 1x relay SPDT Switch. voltage MAX: 125 VAC, 60 VDC Switch. current MAX: 1 A

INPUTS

4x isolated binary - ON (1)/OFF (0) state In. voltage ON state: 5-24V DC In. current ON state: 1.5 mA max

POWER

5V/0.4A max from USB: from AUX: 12-24V DC/2W

120x130x60 mm Dimensions (box): Outline dimensions: 120x145x70 mm

Connections:

Re1 Re16	16x relay
Re-SYS	relay System Ready
CO	COM contact (center)
NC	Norm. closed contact
NO	Norm. open contact
Х	term. not connected
Bi1 Bi4	4x binary inputs
Binary inputs range:	5-24 V

1,4 mA max

for future use

AUX power

AUX power "+ pole"

AUX power "- pole"

data + power connection

++

USB

Ethernet AUX PWR

Note:

All "+ pole" terminals are connected. All "- pole" terminals are connected. AUX power is needed only without USB connection.

Loops – specifications

OUTPUTS

Outputs:

Current range: Input voltage:

16x current loop passive, isolated 3.5-22mA 7V-24V DC

Sys Output: Switch. voltage MAX: Switch. current MAX:

1x relay SPDT 125 VAC, 60 VDC 1 A

INPUTS

4x isolated binary - ON (1)/OFF (0) state In. voltage ON state: 5-24V DC In. current ON state: 1.5 mA max

POWER

from USB: from AUX: 5V/0.2A max 12-24V DC/2W

16x current loop

relay System Ready

COM contact (center)

Norm. closed contact

Norm. open contact

term, not connected

AUX power "+ pole"

AUX power "- pole"

for future use

AUX power

data + power connection

120x130x60 mm Outline dimensions: 120x145x70 mm

Connections:

Dimensions (box):

Lo1 ... Lo16 **Re-SYS** CO NC NO Х

Bi1 ... Bi4 Binary inputs range: 4x binary inputs 5-24 V 1,4 mA max

++ --

USB Ethernet AUX PWR

Note:

All "+ pole" terminals are connected. All "- pole" terminals are connected. AUX power is needed only without USB connection.